

Test	Objects	Status	Remarks
4.1.1	hrMemorySize hrStorageSize hrStorageTypes hrStorageType hrStorageDescr hrStorageUsed	PASSED	Host Resources Storage Group passed
4.1.2	hrDeviceTypes hrDeviceType hrDeviceStatus hrDeviceDescr hrDeviceProcessor hrDeviceNetwork hrDevicePrinter hrDeviceDiskStorage	PASSED	Host Resources Device Table test passed
4.1.3	hrDeviceType hrProcessorLoad hrDeviceProcessor	PASSED	Processor Table Empty
4.1.4	hrDeviceNetwork hrDeviceType hrNetworkIfIndex ifAdminStatus hrDeviceStatus	PASSED	Host Resources Network Table test passed
4.1.5	hrDeviceType hrDeviceStatus hrDeviceDescr hrDevicePrinter	PASSED	Host Printer Table test passed
4.1.6	hrDeviceDiskStorage hrDeviceType hrDiskStorageCapacity hrDiskStorageMedia hrDiskStorageRemoveable hrDiskStorageAccess	PASSED	Disk Storage Table Empty
4.1.7	hrPartitionLabel hrPartitionSize hrPartitionFSIndex hrFSMountPoint	PASSED	Partition Table Empty
4.1.8	hrFSTypes hrFSMountPoint hrFSRemoteMountPoint hrFSType hrFSAccess hrFSBootable hrFSLastPartialBackupDate hrFSLastFullBackupDate	PASSED	File System Table Empty
5.1.1	hrDeviceType hrDeviceDescr hrDevicePrinter	PASSED	Host Printer Table test passed
5.1.2	hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	PASSED	Host Resources Device Status Test Passed

Test	Objects	Status	Remarks
5.2.1	prtGeneralCurrentOperator prtGeneralServicePerson	PASSED	Responsible Party Group Passed
5.2.2	prtCoverStatus prtCoverDescription prtGeneralCurrentLocalization	PASSED	Cover Table Test Passed
5.2.3	prtGeneralReset	PASSED	General Printer Group Test Passed
5.2.4	prtGeneralReset hrPrinterStatus hrDeviceStatus prtMarkerPowerOnCount prtMarkerLifeCount prtMarkerMarkTech prtMarkerDefaultIndex prtGeneralCurrentOperator	FAILED	error noSuchName setting prtMarkerDefaultIndex to 1
5.3.1	prtInputDefaultIndex prtInputMediaName prtInputName prtInputDimUnit prtInputCapacityUnit prtInputType prtInputStatus prtInputMaxCapacity prtInputCurrentLevel	FAILED	error noSuchName setting prtInputMediaDimFeedDirDeclared to 85000
5.3.1	prtInputDefaultIndex prtInputMediaName prtInputName prtInputDimUnit prtInputCapacityUnit prtInputType prtInputStatus prtInputMaxCapacity prtInputCurrentLevel	FAILED	error noSuchName setting prtInputDefaultIndex to 5
5.3.2	prtInputType prtInputDimUnit prtInputMediaDimFeedDirDeclared prtInputMediaDimFeedDirChosen prtInputMediaDimXFeedDirChosen prtInputCapacityUnit prtInputMaxCapacity prtInputCurrentLevel prtInputStatus prtInputMediaName	FAILED	Prerequisite Test 5.3.1 failed
5.3.3	prtInputName prtInputVendorName prtInputModel prtInputVersion prtInputSerialNumber	FAILED	Prerequisite Test 5.3.1 failed

Test	Objects	Status	Remarks
5.3.4	prtInputDescription prtInputSecurity prtGeneralCurrentLocalization	FAILED	Prerequisite Test 5.3.1 failed
5.4.1	prtInputMediaWeight prtInputMediaType prtInputMediaColor prtInputMediaFormParts	PASSED	Output Group Table Test Passed
5.4.2	prtOutputDefaultIndex prtOutputName prtOutputType prtOutputStatus prtOutputCapacityUnit prtOutputType	PASSED	Output Group Test Passed
5.4.3	prtOutputType prtOutputCapacityUnit prtOutputMaxCapacity prtOutputRemainingCapacity prtOutputStatus	PASSED	Extended Output Group test passed
5.4.4	prtOutputName prtOutputVendorName prtOutputModel prtOutputVersion prtOutputSerialNumber prtOutputDescription prtOutputSecurity prtGeneralCurrentLocalization	FAILED	error noSuchName getting prtOutputDimUnit
5.4.4	prtOutputDimUnit prtOutputMaxDimFeedDir prtOutputMaxDimXFeedDir prtOutputMinDimFeedDir prtOutputMinDimXFeedDir	FAILED	error noSuchName getting prtOutputMaxDimFeedDir
5.4.4	prtOutputDimUnit prtOutputMaxDimFeedDir prtOutputMaxDimXFeedDir prtOutputMinDimFeedDir prtOutputMinDimXFeedDir	FAILED	error noSuchName getting prtOutputMaxDimXFeedDir
5.4.4	prtOutputDimUnit prtOutputMaxDimFeedDir prtOutputMaxDimXFeedDir prtOutputMinDimFeedDir prtOutputMinDimXFeedDir	FAILED	error noSuchName getting prtOutputMinDimFeedDir
5.4.4	prtOutputDimUnit prtOutputMaxDimFeedDir prtOutputMaxDimXFeedDir prtOutputMinDimFeedDir prtOutputMinDimXFeedDir	FAILED	error noSuchName getting prtOutputMinDimXFeedDir
5.4.4	prtOutputDimUnit	FAILED	error noSuchName getting prtOutputMinDimXFeedDir

Test	Objects	Status	Remarks
5.4.4	prtOutputMaxDimFeedDir prtOutputMaxDimXFeedDir prtOutputMinDimFeedDir prtOutputMinDimXFeedDir	PASSED	prtOutputDimensionsGroup not implemented
5.4.5	prtOutputDimUnit prtOutputMaxDimFeedDir prtOutputMaxDimXFeedDir prtOutputMinDimFeedDir prtOutputMinDimXFeedDir	PASSED	Output Features Group Passed
5.5.1	prtOutputStackingOrder prtOutputPageDeliveryOrientation \$var	FAILED	error noSuchName setting prtMarkerDefaultIndex to 1
5.5.2	prtMarkerCounterUnit prtMarkerStatus prtMarkerPowerOnCount prtMarkerLifeCount prtMarkerAddressabilityUnit prtMarkerMarkTech prtMarkerProcessColorants prtMarkerSpotColorants prtMarkerMarkTech prtMarkerDefaultIndex prtMarkerNorthMargin prtMarkerSouthMargin prtMarkerEastMargin prtMarkerWestMargin prtMarkerAddressabilityFeedDir prtMarkerAddressabilityXFeedDir	FAILED	Prerequisite Test 5.5.1 failed
5.5.3	prtMarkerAddressabilityUnit prtMarkerAddressabilityFeedDir prtMarkerAddressabilityXFeedDir prtMarkerNorthMargin prtMarkerSouthMargin prtMarkerEastMargin prtMarkerWestMargin prtMarkerSuppliesType prtMarkerPowerOnCount prtMarkerLifeCount	PASSED	Marker Supply Table Test Passed
	prtMarkerSuppliesColorantIndex prtMarkerSuppliesMarkerIndex prtMarkerSuppliesClass prtMarkerSuppliesSupplyUnit prtMarkerSuppliesMaxCapacity prtMarkerSuppliesLevel prtMarkerStatus prtMarkerColorantRole prtMarkerSuppliesDescription		

Test	Objects	Status	Remarks
5.5.4	prtGeneralCurrentLocalization	PASSED	Marker Colorant Table Empty
5.6.1	prtMarkerColorantMarkerIndex prtMarkerColorantRole prtMarkerColorantTonality prtMarkerStatus	PASSED	Media Path Table Test Passed
5.6.2	prtMediaPathMaxSpeedPrintUnit prtMediaPathMediaSizeUnit prtMediaPathType prtMediaPathStatus prtMediaPathMaxSpeed prtMediaPathDescription prtMediaPathDefaultIndex	PASSED	Media Path Group Test Passed
5.7.1	prtMediaPathMaxMediaFeedDir prtMediaPathMaxMediaXFeedDir prtMediaPathMinMediaFeedDir prtMediaPathMinMediaXFeedDir prtMediaPathMediaSizeUnit prtMediaPathType prtMediaPathDescription prtGeneralCurrentLocalization	FAILED	error noSuchName setting prtChannelState to 4
5.8.1	prtChannelType prtChannelState prtChannelStatus prtChannelIndex ifAdminStatus ifInOctets prtInterpreterLangVersion	PASSED	Interpreter Group test passed
5.9.1	prtInterpreterLangFamily prtInterpreterDefaultOrientation prtInterpreterTwoWay prtInterpreterDescription prtGeneralCurrentLocalization	PASSED	The Console Group Test has Passed
5.9.2	prtConsoleNumberOfDisplayLines prtConsoleNumberOfDisplayChars prtConsoleLocalization prtConsoleDisable prtConsoleLocalization prtLocalizationLanguage	FAILED	timeout error on SET
5.9.3	prtConsoleDisplayBufferText	PASSED	Console Light Table test passed
5.10.1	prtConsoleOnTime prtConsoleOffTime prtConsoleDescription printerV1Alert	FAILED	Printer did not issue an expected trap

Test	Objects	Status	Remarks
5.10.2	hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.10.3	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.10.4	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.10.1	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.9.3	prtConsoleOnTime prtConsoleOffTime prtConsoleDescription	PASSED	Console Light Table test passed
5.10.1	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.10.1	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap