

Test	Objects	Status	Remarks
4.1.1	hrMemorySize hrStorageSize hrStorageTypes hrStorageType hrStorageDescr hrStorageUsed	PASSED	Host Resources Storage Group passed
4.1.2	hrDeviceTypes hrDeviceType hrDeviceStatus hrDeviceDescr hrDeviceProcessor hrDeviceNetwork hrDevicePrinter hrDeviceDiskStorage	PASSED	Host Resources Device Table test passed
4.1.3	hrDeviceType hrProcessorLoad hrDeviceProcessor	PASSED	Processor Table Empty
4.1.4	hrDeviceNetwork hrDeviceType hrNetworkIfIndex ifAdminStatus hrDeviceStatus	PASSED	Host Resources Network Table test passed
4.1.5	hrDeviceType hrDeviceStatus hrDeviceDescr hrDevicePrinter	PASSED	Host Printer Table test passed
4.1.6	hrDeviceDiskStorage hrDeviceType hrDiskStorageCapacity hrDiskStorageMedia hrDiskStorageRemoveable hrDiskStorageAccess	PASSED	Disk Storage Table Empty
4.1.7	hrPartitionLabel hrPartitionSize hrPartitionFSIndex hrFSMountPoint	PASSED	Partition Table Empty
4.1.8	hrFSTypes hrFSMountPoint hrFSRemoteMountPoint hrFSType hrFSAccess hrFSBootable hrFSLastPartialBackupDate hrFSLastFullBackupDate	PASSED	File System Table Empty
5.1.1	hrDeviceType hrDeviceDescr hrDevicePrinter	PASSED	Host Printer Table test passed
5.1.2	hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Unexpected hrPrinterStatus

Test	Objects	Status	Remarks
5.2.1		FAILED	error noSuchName setting prtGeneralCurrentOperator to New Operator
	prtGeneralCurrentOperator prtGeneralServicePerson		
5.2.1		FAILED	see window "Failure for Test 5.2.1"
	prtGeneralCurrentOperator prtGeneralServicePerson		
5.2.2		FAILED	Unexpected result
	prtCoverStatus prtCoverDescription prtGeneralCurrentLocalization		
5.2.3		PASSED	General Printer Group Test Passed
	prtGeneralReset		
5.2.4		FAILED	error noSuchName setting prtGeneralCurrentOperator to Operator 2
	prtGeneralReset hrPrinterStatus hrDeviceStatus prtMarkerPowerOnCount prtMarkerLifeCount prtMarkerMarkTech prtMarkerDefaultIndex prtGeneralCurrentOperator		
5.3.1		FAILED	error noSuchName setting prtInputMediaDimFeedDirDeclared to 279400
	prtInputDefaultIndex prtInputMediaName prtInputName prtInputDimUnit prtInputCapacityUnit prtInputType prtInputStatus prtInputMaxCapacity prtInputCurrentLevel		
5.3.1		FAILED	Unexpected Value
	prtInputDefaultIndex prtInputMediaName prtInputName prtInputDimUnit prtInputCapacityUnit prtInputType prtInputStatus prtInputMaxCapacity prtInputCurrentLevel		
5.3.2		FAILED	Prerequisite Test 5.3.1 failed
	prtInputType prtInputDimUnit prtInputMediaDimFeedDirDeclared prtInputMediaDimFeedDirChosen prtInputMediaDimXFeedDirChosen prtInputCapacityUnit prtInputMaxCapacity prtInputCurrentLevel prtInputStatus prtInputMediaName		
5.3.3		FAILED	Prerequisite Test 5.3.1 failed
	prtInputName		

Test	Objects	Status	Remarks
5.3.4	prtInputVendorName prtInputModel prtInputVersion prtInputSerialNumber prtInputDescription prtInputSecurity prtGeneralCurrentLocalization	FAILED	Prerequisite Test 5.3.1 failed
5.4.1	prtInputMediaWeight prtInputMediaType prtInputMediaColor prtInputMediaFormParts	FAILED	Set prtOutputDefaultIndex failed
5.4.2	prtOutputDefaultIndex prtOutputName prtOutputType prtOutputStatus prtOutputCapacityUnit prtOutputType	FAILED	Prerequisite Test 5.4.1 failed
5.4.3	prtOutputType prtOutputCapacityUnit prtOutputMaxCapacity prtOutputRemainingCapacity prtOutputStatus	FAILED	Prerequisite Test 5.4.1 failed
5.4.4	prtOutputName prtOutputVendorName prtOutputModel prtOutputVersion prtOutputSerialNumber prtOutputDescription prtOutputSecurity prtGeneralCurrentLocalization	FAILED	Prerequisite Test 5.4.1 failed
5.4.5	prtOutputDimUnit prtOutputMaxDimFeedDir prtOutputMaxDimXFeedDir prtOutputMinDimFeedDir prtOutputMinDimXFeedDir	FAILED	Prerequisite Test 5.4.1 failed
5.5.1	prtOutputStackingOrder prtOutputPageDeliveryOrientation \$var	PASSED	Marker Table Test Passed
	prtMarkerCounterUnit prtMarkerStatus prtMarkerPowerOnCount prtMarkerLifeCount prtMarkerAddressabilityUnit prtMarkerMarkTech prtMarkerProcessColorants prtMarkerSpotColorants prtMarkerMarkTech prtMarkerDefaultIndex prtMarkerNorthMargin prtMarkerSouthMargin prtMarkerEastMargin prtMarkerWestMargin		

Test	Objects	Status	Remarks
5.5.2	prtMarkerAddressabilityFeedDir prtMarkerAddressabilityXFeedDir	PASSED	Marker Group Test Passed
5.5.3	prtMarkerAddressabilityUnit prtMarkerAddressabilityFeedDir prtMarkerAddressabilityXFeedDir prtMarkerNorthMargin prtMarkerSouthMargin prtMarkerEastMargin prtMarkerWestMargin prtMarkerSuppliesType prtMarkerPowerOnCount prtMarkerLifeCount	PASSED	prtMarkerSuppliesTable is empty
5.5.4	prtMarkerSuppliesColorantIndex prtMarkerSuppliesMarkerIndex prtMarkerSuppliesClass prtMarkerSuppliesSupplyUnit prtMarkerSuppliesMaxCapacity prtMarkerSuppliesLevel prtMarkerStatus prtMarkerColorantRole prtMarkerSuppliesDescription prtGeneralCurrentLocalization	PASSED	Marker Colorant Table Empty
5.6.1	prtMarkerColorantMarkerIndex prtMarkerColorantRole prtMarkerColorantTonality prtMarkerStatus	PASSED	Media Path Table Test Passed
5.6.2	prtMediaPathMaxSpeedPrintUnit prtMediaPathMediaSizeUnit prtMediaPathType prtMediaPathStatus prtMediaPathMaxSpeed prtMediaPathDescription prtMediaPathDefaultIndex	FAILED	Unexpected result
5.7.1	prtMediaPathMaxMediaFeedDir prtMediaPathMaxMediaXFeedDir prtMediaPathMinMediaFeedDir prtMediaPathMinMediaXFeedDir prtMediaPathMediaSizeUnit prtMediaPathType prtMediaPathDescription prtGeneralCurrentLocalization prtChannelType prtChannelState	FAILED	iflnOctects.2 did not increase enough

Test	Objects	Status	Remarks
5.8.1	prtChannelStatus prtChannelIfIndex ifAdminStatus ifInOctets prtInterpreterLangVersion	FAILED	Orientation changed not validated
5.9.1	prtInterpreterLangFamily prtInterpreterDefaultOrientation prtInterpreterTwoWay prtInterpreterDescription prtGeneralCurrentLocalization	FAILED	error noSuchName setting prtConsoleDisable to 4
5.9.2	prtConsoleNumberOfDisplayLines prtConsoleNumberOfDisplayChars prtConsoleLocalization prtConsoleDisable prtConsoleLocalization prtLocalizationLanguage	FAILED	error noSuchName setting prtConsoleDisplayBufferText to XXX
5.9.3	prtConsoleDisplayBufferText	FAILED	Unexpected Result
5.10.1	prtConsoleOnTime prtConsoleOffTime prtConsoleDescription	FAILED	Printer did not issue an expected trap
5.10.2	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.10.3	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Test was cancelled
5.10.4	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Test was cancelled
5.10.1	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.9.3	prtConsoleOnTime prtConsoleOffTime prtConsoleDescription	PASSED	Console Light table test passed
5.10.1	printerV1Alert hrDeviceStatus	FAILED	Printer did not issue an expected trap

<b>Test</b>	<b>Objects</b>	<b>Status</b>	<b>Remarks</b>
5.10.1	hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Printer did not issue an expected trap
5.10.3	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Test was cancelled
	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState		