

Test	Objects	Status	Remarks
4.1.1	hrMemorySize hrStorageSize hrStorageTypes hrStorageType hrStorageDescr hrStorageUsed	FAILED	error noSuchName getting hrMemorySize
4.1.2	hrDeviceTypes hrDeviceType hrDeviceStatus hrDeviceDescr hrDeviceProcessor hrDeviceNetwork hrDevicePrinter hrDeviceDiskStorage	PASSED	Host Resources Device Table test passed
4.1.3	hrDeviceType hrProcessorLoad hrDeviceProcessor	PASSED	Processor Table Empty
4.1.4	hrDeviceNetwork hrDeviceType hrNetworkIfIndex ifAdminStatus hrDeviceStatus	PASSED	Host Resources Network Table test passed
4.1.5	hrDeviceType hrDeviceStatus hrDeviceDescr hrDevicePrinter	PASSED	Host Printer Table test passed
4.1.6	hrDeviceDiskStorage hrDeviceType hrDiskStorageCapacity hrDiskStorageMedia hrDiskStorageRemoveable hrDiskStorageAccess	PASSED	Disk Storage Table Empty
4.1.7	hrPartitionLabel hrPartitionSize hrPartitionFSIndex hrFSMountPoint	PASSED	Partition Table Empty
4.1.8	hrFSTypes hrFSMountPoint hrFSRemoteMountPoint hrFSType hrFSAccess hrFSBootable hrFSLastPartialBackupDate hrFSLastFullBackupDate	PASSED	File System Table Empty
5.1.1	hrDeviceType hrDeviceDescr hrDevicePrinter	PASSED	Host Printer Table test passed
5.1.2	hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	FAILED	Unexpected hrPrinterStatus

Test	Objects	Status	Remarks
5.2.1		FAILED	error noSuchName getting prtGeneralCurrentOperator
	prtGeneralCurrentOperator prtGeneralServicePerson		
5.2.2		FAILED	error noSuchName setting prtGeneralCurrentLocalization to 2
	prtCoverStatus prtCoverDescription prtGeneralCurrentLocalization		
5.2.2		FAILED	Alert not found in alert table
	prtCoverStatus prtCoverDescription prtGeneralCurrentLocalization		
5.2.2		FAILED	Unexpected status value
	prtCoverStatus prtCoverDescription prtGeneralCurrentLocalization		
5.2.2		PASSED	Cover Table Test Passed
	prtCoverStatus prtCoverDescription prtGeneralCurrentLocalization		
5.2.3		PASSED	General Printer Group Test Passed
	prtGeneralReset		
5.2.4		FAILED	error noSuchName setting prtMarkerDefaultIndex to 1
	prtGeneralReset hrPrinterStatus hrDeviceStatus prtMarkerPowerOnCount prtMarkerLifeCount prtMarkerMarkTech prtMarkerDefaultIndex prtGeneralCurrentOperator		
5.3.1		FAILED	error noSuchName setting prtInputMaxCapacity to 100
	prtInputDefaultIndex prtInputMediaName prtInputName prtInputDimUnit prtInputCapacityUnit prtInputType prtInputStatus prtInputMaxCapacity prtInputCurrentLevel		
5.3.1		FAILED	error noSuchName getting prtInputName
	prtInputDefaultIndex prtInputMediaName prtInputName prtInputDimUnit prtInputCapacityUnit prtInputType prtInputStatus prtInputMaxCapacity prtInputCurrentLevel		
5.3.1		FAILED	error noSuchName getting prtInputMediaName
	prtInputDefaultIndex prtInputMediaName prtInputName prtInputDimUnit prtInputCapacityUnit		

Test	Objects	Status	Remarks
5.3.2	prtInputType prtInputStatus prtInputMaxCapacity prtInputCurrentLevel	FAILED	Prerequisite Test 5.3.1 failed
5.3.3	prtInputType prtInputDimUnit prtInputMediaDimFeedDirDeclared prtInputMediaDimFeedDirChosen prtInputMediaDimXFeedDirChosen prtInputCapacityUnit prtInputMaxCapacity prtInputCurrentLevel prtInputStatus prtInputMediaName	FAILED	Prerequisite Test 5.3.1 failed
5.3.4	prtInputName prtInputVendorName prtInputModel prtInputVersion prtInputSerialNumber prtInputDescription prtInputSecurity prtGeneralCurrentLocalization	FAILED	Prerequisite Test 5.3.1 failed
5.4.1	prtInputMediaWeight prtInputMediaType prtInputMediaColor prtInputMediaFormParts	FAILED	error noSuchName getting prtOutputName
5.4.1	prtOutputDefaultIndex prtOutputName prtOutputType prtOutputStatus prtOutputCapacityUnit prtOutputType	FAILED	error noSuchName getting prtOutputName
5.4.1	prtOutputDefaultIndex prtOutputName prtOutputType prtOutputStatus prtOutputCapacityUnit prtOutputType	PASSED	Output Group Table Test Passed
5.4.2	prtOutputDefaultIndex prtOutputName prtOutputType prtOutputStatus prtOutputCapacityUnit prtOutputType	FAILED	Expected alert in status
5.4.2	prtOutputType prtOutputCapacityUnit prtOutputMaxCapacity prtOutputRemainingCapacity prtOutputStatus	FAILED	Expected alert in status

Test	Objects	Status	Remarks
5.4.2	prtOutputType prtOutputCapacityUnit prtOutputMaxCapacity prtOutputRemainingCapacity prtOutputStatus	FAILED	Expected alert in status
5.4.3	prtOutputType prtOutputCapacityUnit prtOutputMaxCapacity prtOutputRemainingCapacity prtOutputStatus	FAILED	error noSuchName getting prtOutputName
5.4.5	prtOutputName prtOutputVendorName prtOutputModel prtOutputVersion prtOutputSerialNumber prtOutputDescription prtOutputSecurity prtGeneralCurrentLocalization	PASSED	Output Features Group Passed
5.5.1	prtOutputStackingOrder prtOutputPageDeliveryOrientation \$var	FAILED	error noSuchName setting prtMarkerDefaultIndex to 1
5.5.2	prtMarkerCounterUnit prtMarkerStatus prtMarkerPowerOnCount prtMarkerLifeCount prtMarkerAddressabilityUnit prtMarkerMarkTech prtMarkerProcessColorants prtMarkerSpotColorants prtMarkerMarkTech prtMarkerDefaultIndex prtMarkerNorthMargin prtMarkerSouthMargin prtMarkerEastMargin prtMarkerWestMargin prtMarkerAddressabilityFeedDir prtMarkerAddressabilityXFeedDir	FAILED	Prerequisite Test 5.5.1 failed
5.5.3	prtMarkerAddressabilityUnit prtMarkerAddressabilityFeedDir prtMarkerAddressabilityXFeedDir prtMarkerNorthMargin prtMarkerSouthMargin prtMarkerEastMargin prtMarkerWestMargin prtMarkerSuppliesType prtMarkerPowerOnCount prtMarkerLifeCount prtMarkerSuppliesColorantInd	FAILED	Invalid type 1 enumeration

Test	Objects	Status	Remarks
5.5.4	ex prtMarkerSuppliesMarkerIndex prtMarkerSuppliesClass prtMarkerSuppliesSupplyUnit prtMarkerSuppliesMaxCapacity prtMarkerSuppliesLevel prtMarkerStatus prtMarkerColorantRole prtMarkerSuppliesDescription prtGeneralCurrentLocalization	PASSED	Marker Colorant Table Empty
5.6.1	prtMarkerColorantMarkerIndex prtMarkerColorantRole prtMarkerColorantTonality prtMarkerStatus	PASSED	Media Path Table Test Passed
5.6.2	prtMediaPathMaxSpeedPrintUnit prtMediaPathMediaSizeUnit prtMediaPathType prtMediaPathStatus prtMediaPathMaxSpeed prtMediaPathDescription prtMediaPathDefaultIndex	FAILED	error noSuchName setting prtGeneralCurrentLocalization to 2
5.7.1	prtMediaPathMaxMediaFeedDir prtMediaPathMaxMediaXFeedDir prtMediaPathMinMediaFeedDir prtMediaPathMinMediaXFeedDir prtMediaPathMediaSizeUnit prtMediaPathType prtMediaPathDescription prtGeneralCurrentLocalization	FAILED	error noSuchName getting prtChannelIfIndex
5.8.1	prtChannelType prtChannelState prtChannelStatus prtChannelIfIndex ifAdminStatus ifInOctets prtInterpreterLangVersion	FAILED	error noSuchName setting prtGeneralCurrentLocalization to 2
5.9.1	prtInterpreterLangFamily prtInterpreterDefaultOrientation prtInterpreterTwoWay prtInterpreterDescription prtGeneralCurrentLocalization prtConsoleNumberOfDisplayLines prtConsoleNumberOfDisplayChars	PASSED	The Console Group Test has Passed

Test	Objects	Status	Remarks
5.9.2	prtConsoleLocalization prtConsoleDisable prtConsoleLocalization prtLocalizationLanguage	FAILED	error noSuchName setting prtConsoleDisplayBufferText to XXX
5.9.3	prtConsoleDisplayBufferText	PASSED	Console Light Table test passed
5.10.1	prtConsoleOnTime prtConsoleOffTime prtConsoleDescription	PASSED	Printer doesn't send traps
5.10.2	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	PASSED	Printer doesn't send traps
5.10.3	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	PASSED	Printer doesn't send traps
5.10.4	printerV1Alert hrDeviceStatus hrPrinterStatus hrPrinterDetectedErrorState	PASSED	Printer doesn't send traps